




Mingfans Air Ltd





- | | | |
|----|--|---|
| D1 | | D1 ELECTRIC DAMPER
SUMMERKITS FRESH AIR SUPPLY OUTSIDE |
| D2 | | D2 ELECTRIC DAMPER
VENTILATION/HEAT TRANSFR MODE
OTHERS |
| D3 | | D3 ELECTRIC DAMPER
ROOF SPACE GRILLES |
| D4 | | D4 ELECTRIC DAMPER
HEAT TRANSFER GRILLES |
| D5 | | D5 ELECTRIC DAMPER
LIVING ROOM RETURN GRILLES |

- | | |
|--|--|
| | INTAKE AIR EGGRATE
GRILLE
AND FRESH AIR GRILLE |
| | SUPPLY AIR ROUND CEILING
DIFFUSERS |
| | SOUND PROVE ACUSTIC DUCTING
BETWEEN FAN
AND INSULATED DUCTING FOR
THE REST CONNECTION |
| | Y PIECE FOR DIFFEENT
OUTLET CONNECTION |



Mingfans Air Ltd






S = SUMMER KITS
H = HEAT TRANSFER SOURCE
R = ROOF SPACE VENTILATION


ALL IN ONE HOME VENTILATION COOL & HEAT FUNCTION

WE HAVE WIRED & SET UP TO SUIT EACH SYSTEM
PLEASE READ THE SETUP BOOKLET CAREFULLY BEFORE SET UP .

BLACK CONTROLLER




COOL MODE SUMMERKITS & VENTILATION



Summer Day Time Cool Mode
Room Temp Above Set Temp
COOL ON
Summer damper opening
high speeds fresh air outside




HEAT MODE HEAT TRANSFER & VENTILATION




Winter Time Heat Mode
Room Temp Below Set Temp
HEAT ON
Heat transfer Damper opening
high speeds air from heat source




VENTILATION MODE



VENTILATION ONLY
ALWAYS TAKE AIR FROM ROOF SPACE
BEST USE FOR CONDENSATION CONTROL



HEAT & COOLING AUTO MODE



HEAT & COOLING AUTOMATIC SWITCH MODE
THIS MODE WILL AUTOMATIC SWITCH BETWEEN HEAT MODE AND COOLING MODE

1. WHEN YOU SET TEMP ABOVE ROOM TEMP IT WILL AUTOMATIC HEAT TRANSFER FROM HEAT SOURCE
2. WHEN YOU SET TEMP BELOW ROOM TEMP IT WILL AUTOMATIC SUMMER KITS TAKING AIR FROM OUTSIDE

WIFI& CLOUD Sign

NOT show up means no wifi connection

DATE & TIME


DATE&TIME

ROOM TEMP

ON STAD BY MODE
WILL ONLY SHOW
ROOM TEMP

SET TEMP

PRESS UP&DOWN
KEY TO CHANGE
SET TEMP



MODE/SETUP

MODE CHANGING

FANSPEED

HIGH MED LOW
AND AUTO

SETTING TEMPERATURE


INC/DEC SETTING
TEMPERATURE




COOL MODE
SUMMERKITS & VENTILATION




HEAT MODE
HEAT TRANSFER & VENTILATION



Summer Day Time Cool Mode
Room Temp Above Set Temp
COOL ON
Summer damper opening
high speeds fresh air outside




Winter Time Heat Mode
Room Temp Below Set Temp
HEAT ON
Heat transfer Damper opening
high speeds air from heat source




VENTILATION MODE



HEAT & COOLING AUTO MODE



VENTILATION ONLY
ALWAYS TAKE AIR FROM ROOF SPACE
BEST USE FOR CONDENSATION CONTROL





HEAT & COOLING AUTOMATIC SWITCH MODE
THIS MODE WILL AUTOMATIC SWITCH BETWEEN HEAT
MODE AND COOLING MODE

1.WHEN YOU SET TEMP ABOVE ROOM TEMP IT WILL
AUTOMATIC HEAT TRANSFER FROM HEAT SOURCE

2.WHEN YOU SET TEMP BELOW ROOM TEMP IT WILL
AUTOMATIC SUMMER KITS TAKING AIR FROM OUTSIDE

WIFI SET UP SMART LIFE/TUYA SMART




AFTER DOWNLOAD APP SMART LIFE FROM APP STORE
FILL UP THE REGISTRATION
LET'S START TO ADD ON YOUR DEVICE



STEP 1 PRESS ADD +



STEP 2 PRESS:
THERMOSTAT ICON




STEP 3&3B: PLS PUT IN YOUR WIFI PASS WORD MAKE SURE
ITS 2.4GHZ NOT 5GHZ .FEEL FREE TO READ STEP 4 &5 TO
ACTIVE WIFI THEN PRESS CONFIRM




STEP 4 HOW TO ACTIVE WIIF
ON CONTROL PANEL



STEP 5 HOW TO ACTIVE WIIF
ON CONTROL PANEL



AUTO SET UP MAY TAKE 2MIN
PLS NOTES WIFI ON 2.4G
ONLY 5G NOT ACCEPTABLE




ALL DONE READY TO USE





MINGFANS AIR LTD
WWW.MINGFANS.CO.NZ
B9 1066 GREAT SOUTH ROAD
MT WELLINGTON AUCKLAND 1060
092762745 021826760
QUCKY@HOTMAIL.COM
MINGFANS_MOTOR@HOTMAIL.COM


APP PANEL FUNCTION




MODE CONTROL



FAN SPEEDS





ON/OFF



7 DAYS PROGRAM /
MANUAL

SLEEP MODE ON/OFF

ADV. SETUP
ALL ADVANCED SET UP
REQUEST PASSWORD TO RESET
FACTORY PASSWORD "123456"



MINGFANS AIR LTD
WWW.MINGFANS.CO.NZ
B9 1066 GREAT SOUTH ROAD
MT WELLINGTON AUCKLAND 1060
092762745 021826760
QUCKY@HOTMAIL.COM
MINGFANS_MOTOR@HOTMAIL.COM

FAN ENERGY SAVE MODE (ECO MODE) WHEN TEMP REARCH FAN TURN OFF INSTEAD IN LOW SPEEDS
TS SYSTEM RECOMMEND NOT SET TO ENERGY SAVE MODE SO VENTILATION CAN 24/7.